

# **OVEN**

## *Safety*

**HOT - Use pliers or metal bars or welding gloves to handle hot parts.**

**FUMES - Turn Fume Exhaust fan on.**

**Make sure parts to be powder coated will fit in oven.**

**Open oven door and prepare hanging hardware and racks for placement of parts to be cured.**

**Turn Oven on by pressing BAKE.**

**Enter a value that corresponds to the powder coat paint you are using.**

**Use CANCEL button if value is entered incorrectly.**

**Set TIMER when ready and set in accordance to the powder coat paint can instructions.**

**Close oven door until parts are ready.**

**Press CANCEL to shut down oven.**

**Open oven door, to allow parts to cool down, do not turn Fume exhaust fan off until parts have cooled.**