## **POWDER COAT SPRAY BOOTH**

## Safety

Wear- Safety Glasses, disposable gloves, dust mask or respirator

Turn on - Fume extraction fan

Turn on booth lights.

Choose colour.

Clean gun or guns thoroughly and carefully attach bottle of desired colour.

Adjust Air regulator to 15 or 20 PSI or 1.5 Bar.

Attach air quick connect hose line.

Attach ground clamp to metal grid or rotating hanger bar or object.

Plug in gun or guns.

For Redline gun, pull trigger to activate electrical discharge powder transfer to object.

For HV Powder Coat system gun, switch on control box and press foot pedal to activate electrical discharge powder transfer to object.

Clean guns thoroughly if another colour is desired.

Clean powder coat booth after use, by using a vacuum cleaner.