



Agilent E5061B Network Analyzer Help



The E5061B help provides an easy access to the information related to the use of Agilent E5061B Network Analyzer. Pressing **Help** key on the front panel displays the topic related to the selected softkey.

You can navigate this help system through the navigation tools provided in the left or you can directly access the chapters:

For impedance measurement, see Option 005 Impedance Analysis

 Critical Information

 Precautions

 Quick Start

 Setting Control Functions

 Measurement


 Using Windows

 Measurement with Options

 Programming

 Product Information

 Revision History

 Using this Help **(Read me first)**

 Specifications

E5061B Firmware Revision	A.02.0x
Help Edition No.	2.0
Help Revision Date	October 15,2010



© Copyright 2010 Agilent Technologies