


Channel Characteristics and Impairments

Frequency Response


The frequency response of the channel is also called the frequency-domain transfer function, $H(f)$. It is the ratio of the voltage at the output of the channel to the voltage at the input of the channel. It is a complex quantity (includes both amplitude and phase) and is a function of frequency. The ratio of the voltages is called the amplitude response and the ratio of the phases is called the phase response.

If the channel only passes low frequencies it is called a low-pass channel. A typical example is a telephone line. High-pass channels typically result from capacitive or inductive coupling which blocks DC or low-frequency signals.




An all-pass channel has a flat amplitude response which would appear to have no effect on the signal but the phase response may be non-linear (see below).

A band-pass channel is very common. Some band-pass channels result from attenuation by the channel and other are band-pass due to filtering by the transmitter and/or receiver.




Channels often include several of the above characteristics. For example, a twisted pair loop may include a notch filter to remove 50Hz or 60Hz power line noise, it may have peaks and valleys in the frequency response due to reflections from taps or poor terminations and it will drop off with frequency due to higher losses at higher frequencies.




Bandwidth

There are several definitions of bandwidth.

A common definition is the *3dB bandwidth*. This refers to the frequency range where the amplitude response is less than 3dB down from the maximum. Thus a signal component transmitted at the edge of the passband would have half of the power it would have if transmitted at the frequency with the lowest loss. Other bandwidth definitions can use values other than 3dB.



A definition of bandwidth that is often applied to signals rather than channels is the *90% power bandwidth*. This is the frequency range that contains 90% of the signal power. Other values than 90% can be used.




Other definitions of bandwidth are used for specialized purposes.

Bandwidth is a single number and cannot describe all aspects of the transfer function. Other specifications such as the steepness of the filter roll-off or gain ripple in the passband are often important.

Phase Response

The phase response of the channel is the ratio of the phase at the output to the phase at the input. Since the phase “wraps” every 2π , the phase response may have discontinuities.

Phase shifts are often a result of delays through the channel. A time delay of τ introduces a phase shift of $2\pi f\tau$ (radians). The phase shift is a linear function of the delay with the delay defining the slope of the phase versus frequency curve.



Exercise 1: A 100m transmission line has a velocity factor of 0.66. Plot the phase response of the cable over the frequency range 0 to 6 MHz.

Group Delay

If the delay is constant across frequency then:

- the phase response is linear
- all frequency components will be delayed by the same amount and waveforms will not be distorted

However if some frequencies have longer delays than others or the phase is not a linear function of frequency then the waveform will be distorted (assuming it contains those frequencies).

Group delay is a measure of how the phase response of the channel deviates from the ideal linear response. It is defined as the derivative (or slope) of the phase response. Thus a channel with a linear phase response has a constant (flat) group delay.


If the slope of the phase response curve has units of radians and the frequency axis has units of radians/second then the slope (the group delay) will have

units of seconds. Variations in group delay correspond to differences in delay that the different frequency components of a signal will experience. To avoid distortion the peak group delay of the channel should be limited to a small fraction of the symbol duration.


Exercise 2: A telephone line is being used to transmit symbols at a rate of 300 symbols/second. If the group delay must be less than 10% of the symbol period, what is the maximum allowable group delay?

Echo and Multipath

Another source of linear distortion is echoes and multipath propagation. Echoes can be due to transmission lines that are tapped or not properly terminated.



Multipath propagation typically happens on wireless links with non-line of sight (NLOS) paths. Objects will reflect, diffract or scatter the radio signals.



Since the each path length can be different, the delays for each path can be different. The different paths can add up constructively or destructively depending on the frequency and the delay. The frequency response can thus have peaks and nulls.

Non-Linear Distortion

Distortions caused by the amplitude and phase response of the channel are called linear distortions because they can be produced by linear operations on the signal. Linear distortions can be corrected, in principle, by applying a linear filter whose response, at each frequency, is the (complex) multiplicative inverse of the frequency response of the channel. Linear distortion does not affect the frequencies present in the signal.

There are some common distortions that are not linear. A typical example is clipping (the peaks of the signal are cut off) due to the limited dynamic range of an amplifier. Most amplifiers have some degree of non-linearity which causes non-linear distortion.

Non-linear distortion results in additional frequency components being generated. The exact frequencies and strengths of these components depend on the type of distortion and the frequency components of the original signal. Typically there will be harmonics of the frequency components at the input as well as frequencies that are combinations of these harmonics. The frequency components that appear at frequencies that are sums of the harmonics are called inter-modulation distortion, (IMD). The frequencies of the intermodulation products will be:

$$f_{IM} = nf_1 \pm mf_2$$

where n and m are integers. The *order* of the IMD product is defined as $n + m$.

Exercise 3: The input to a non-ideal amplifier is the sum of two sine waves at frequencies of 1 and 1.2 MHz. What are the frequencies of the even harmonics of these frequencies? Of the odd harmonics? What are the frequencies of the third-order IMD products?

Noise

Noise is a random (unpredictable) signal that is added to the desired signal. Noise can be added by the channel or by the receiver.

Noise is the phenomenon that ultimately limits the performance of any communication system. Noise may cause errors in digital communication system or degrade the quality of an analog signal.

One important metric is the signal-to-noise ratio (SNR) which is the ratio of signal power to noise power.

Exercise 4: A sinusoidal signal is being transmitted over a noisy telephone channel. The voltage of the signal is measured with an oscilloscope and is found to have a peak voltage of 1V. Nearby machinery is inducing a noise voltage onto the line. The voltage of this noise signal is measured with an RMS voltmeter as 100mVrms. The characteristic impedance of the line is 600Ω and it is terminated with that impedance. What is the signal power? What is the noise power? What is the SNR?

Similar power ratios that are sometimes used are:

- SIR - signal to interference ratio
- SINR - signal to interference plus noise ratio
- SINAD - signal to interference plus noise and distortion ratio

Thermal Noise

Any resistor at a temperature above absolute zero generates a noise voltage due to the thermal motion of electrons. The voltage of this noise has a Gaussian probability distribution and a flat (constant) frequency spectrum.

The power of this noise in a bandwidth B is given by the equation:

$$N = kTB$$

where k is a constant known as Boltzman's constant, T is the resistor's temperature in Kelvin and B is the bandwidth in Hertz.

Amplifiers and other active devices will output more thermal noise than would be predicted from just considering their input impedance and the gain. The increase in noise power above the noise that would be generated by a resistor is called the noise figure (F) of the amplifier. It is usually quoted in dB. This noise figure in dB must be added when computing the thermal noise power at the output of an active device. In this case the output power of the amplifier (not including the gain) is:

$$N = kTBF$$

If the computation is done in dB units, the value of k is -174 dBm/Hz at 290K (\approx room temperature). To compute the thermal noise power in dBm we must add the bandwidth in dB-Hz ($10\log B$). In this case the equation is:

$$N_{dBm} = -174 + 10\log(B) + 10\log(F)$$


Exercise 5: A line amplifier for a cable TV system amplifies the range of frequencies from 54-1002 MHz. The amplifier has a gain of 30 dB and a noise figure of 3 dB. If we connect a 75Ω resistor (the input impedance of the amplifier) to the input how much power will we measure at the output of the amplifier?

Probability Distribution

If the noise voltage has a Gaussian probability distribution (sometimes called “normally distributed”) with zero mean and variance σ^2 then the probability that the noise will exceed a value v can be computed using the complementary error function:

$$P(x > v) = \frac{1}{2} \operatorname{erfc}\left(\frac{v}{\sigma\sqrt{2}}\right)$$

Since most noise is normally distributed, this function is used to predict the probability of error for many communication systems.



Exercise 6: The output of a noise source has a Gaussian (normally) distributed output voltage. The (rms) output power is 20mW and the output impedance is 100 Ω . What fraction of the time does the output voltage exceed 300mV? Hint: the variance (σ^2) of a signal is the same as the square of its RMS voltage.

Other Noise Sources

Noise can also be generated by commutators in motors or switches. This noise typically consists of short pulses with a wide spectrum.


Crosstalk

Crosstalk is noise due to coupling between conductors that are run in the same cable. For example, telephone loops are often carried in cables with 25 or more pairs. There will be some coupling between the pairs. Signals on one pair can thus leak into another pair in the same cable. Another example is the coupling between pairs used in LAN UTP cables. Crosstalk will be affected by shielding, twist patterns and other design details. Datasheets will often specify crosstalk at different frequencies.

There are two types of crosstalk.

- Near-end crosstalk (NEXT) is the leakage of the signal being transmitted onto the signal being received at the same location.

- Far-end crosstalk (FEXT) is the leakage of the signal being transmitted onto the signal being received at the other end of the link.



Note that the coupling between pairs in a cable happens throughout the length of the cable. The difference between NEXT and FEXT is in which receiver is affected (the near one or the far one), not where the coupling takes place.

“Alien crosstalk” refers to crosstalk from other cables. It is usually not possible to cancel out this crosstalk. Power sum (PS) crosstalk refers to the sum of the crosstalk from all of the other pairs in the cable.

Advanced DSL systems measure the coupling between pairs and subtract out the crosstalk.

Interference

Interference is the presence of signals from another communication system or other users of the same system in the passband of the desired signal. For example:

- the signal from a cell phone may couple onto a phone line and cause a “buzzing” noise.
- at night the signal from a remote AM broadcast station may reach further than usual and cause interference to a local station.
- two WLAN cards may decide to transmit a packet at the same time resulting in neither one being received correctly (both packets are “lost”).

Wireless systems are particularly vulnerable to interference because of the wide difference in the levels of the transmitted and received signals. Wireless systems classify own-system interference into Co-Channel (same channel), Adjacent Channel (next channel) and Alternate Channel (next to the next channel).